

Additional Accessories

PCX-LCD/UK

LCD RKP with in-built Prox Reader

- Robust 32 character full English text keypad with in-built Proximity Reader, eliminates user error in arming/disarming.
- Horizontal & vertical recessed cable channels guarantee ease of installation
- 2 in-built Zones and 1 PGM



FPPCX-LCD/UK

PCX-PROX/INT

Internal Proximity Reader

- 2 in-built zones and 2 PGMs
- Ability to arm/ disarm the Control Panel
- Ability to activate / deactivate PGMS used to open doors



FPPCX-PROX/INT

PCX-PROX/EXT

External Proximity Reader

- IP65 Rated
- Ability to arm/disarm the system
- System status highly visible when a valid Prox Card is presented to the Reader



FPPCX-PROX/EXT

PCX-PTAG

Pack of 5 Prox Tags

- For use with Internal & External Prox Readers



FPPCX-PTAG

PCX-RIX2

2 Zone Expander

- 1 PGM
- Each input can be mapped to any output
- 1 Extension speaker output




FPPCX-RIX2

PCX-RIX8

8 Zone Expander - no PGMs

- Supplied in polymer housing



FPPCX-RIX8

PCX-RIX8+

8 Zone Expander Module with 4 PGMs

- Each input can be mapped to any output
- Supplied in polymer housing



FPPCX-RIX8+

PCX-RIX8+/PSU

8 Zone Expander Module with 4 PGMs and 1.5 amp PSU


- Each input can be mapped to any output
- Supplied in metal housing



FPPCX-RIX8+/PSU

PCX-ROX16R**16 Relay Output Module (ROX)**

- Fully programmable and can be mapped to each input
- Effortless installation - eliminates the use of standard transistor outputs and then fitting separate relays
- Metal housing available to hold 4 x PCX-ROX16R providing a total of 64 outputs



FPPCX-ROX16R

PCX-ACCESS**Access Control Pack**

- 1 Door unit plus IP65 rated External Reader
- With Intelligent Power Supply (1.5 amp)



FPPCX-ACCESS

PCX-PROXSHROUD**Metal Shroud For External Prox Reader**

- Tamper proof metal housing
- Available in a selection of finishes



FPPCX-PROXSHROUD

PCX-CABINET**PCX Metal Housing**

- Metal housing to hold 4 Relay Output Modules (PCX-ROX16R) providing a total of 64 outputs



FPPCX-CABINET

PCX-TCPIP**IP Card**

- Allows the use of TCIP Protocol between panel and monitoring station



Information on request

PCX-RS232L**RS232 - PC link cable**

- Allows connection to a PC for local programming



FPPCX-RS232L

PCX-DIGI + ARM**Automatic Remote Maintenance Software**

- Enables remote servicing and maintenance



FPPCX-DIGI+ARM

INSITE UDL Software**Up/downloading Software**

- Enables programming and diagnostics from a PC

Available from
www.pyronix.com**PCX-INSTCD**

A collection of software and manuals for the PCX-8128 panel including INSITE-UDL programming software



FP12000